

Connector Maintenance:

- A daily, weekly and periodic inspection of the connector by competent person is recommended. User must establish a regular interval for maintenance as determined by the user media and operational environment.
- Inspection should include visual checks of the ball sealing area, sleeve, missing or loose components, leak tightness, ease of operation, sufficient lubrication, wear, dirt accumulation and damage.
- Establish a regular interval for lubrication. The media and environment will be determining factors in establishing this interval to prevent dryness and/or corrosion.
- Difficulty of operation after continual use indicates a need for lubrication or other maintenance.
- Use only original **FasTest** spare parts that are designed for the application and are subject to strict quality control. See Warranty.

Safety Warnings – Guidelines:

- If instructions are not completely understood by operator or components are missing, contact **FasTest** before attempting use of the connector.
- **FasTest CMRQD Connector requires reclaiming through an external vacuum** to prevent loss of media when disconnected. Do not attempt to disconnect unless safe conditions are met.
- **FasTest CMRQD** Connectors must only be used with test pieces of a specific size as indicated by the part number. Improper use could cause separation of the connector from the test piece resulting in physical harm or damage.


FasTest, Inc. Product Warranty

FasTest, Inc. warrants its products against defects of workmanship and/or material for 12 months from the date of the sale by FasTest, Inc. This warranty is void if the product is misused, tampered with or used in a manner that is not in accordance with FasTest, Inc. recommendations and/or instructions. FasTest, Inc. is not liable for consequential or other damages including, but not limited to, loss, damage, personal injury, or any other expense directly or indirectly arising from the use of or inability to use its products either separately or in combination with other products. ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, WHETHER ORAL OR WRITTEN, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.

Remedy under this warranty is limited to replacement of the product or an account credit in the amount of the original selling price, at the option of FasTest, Inc. All allegedly defective products must be returned prepaid transportation to FasTest, Inc. along with information describing the products performance, unless disposition in the field is authorized in writing by FasTest, Inc.

CMRQD Lever Activated Connector

Description: RQD “Refrigeration Quick Disconnect” for CoreMax Fittings.



CMRQD Connector provides a reliable leak-tight connection that grips and seals a CoreMax Fitting. Simply insert male end of fitting and slide sleeve forward, gripping balls will secure fitting.

Please thoroughly read and understand these operating instructions prior to operating the connector. The use of pressurized media for filling and sealing requires a thorough understanding of the **FasTest CMRQD** Operating Instructions.

- Operation
- Connector Maintenance
- Safety Warnings - Guidelines

OPERATING INSTRUCTIONS FOR COREMAX RQD CONNECTORS



Installation:

Connect charge hose securely to the NPT Termination of the **CMRQD** Connector.



Operation:

Connecting Action:

1. Retract sleeve and position lever as shown.

Sleeve Retracted Manually



2. Insert CoreMax fitting and slide sleeve forward collapsing balls around the CoreMax fitting.



CoreMax Fitting Inserted



Sleeve Forward Manually

3. Rotate lever on connector.



Lever Rotation


4. **CMRQD** is now sealed on CoreMax fitting and valve is open for flow.

Note: The Sleeve Will "Lock" Under Pressure to Prevent Accidental Disconnect.




Reclaiming Action:

1. Rotate lever from open to closed position. This will close the valve and trap refrigerant in the connector.



2. Stop flow of refrigerant through connector. With CoreMax fitting still attached reclaim trapped refrigerant through Reclaim Port.



Disconnecting Action

1. After trapped refrigerant is reclaimed slide sleeve away from CoreMax fitting.



2. Remove CoreMax fitting.

